



SYNTHESIS INSTALLATION KIT UPGRADE INSTRUCTIONS

What is in the Installation kit.

2 Joining brackets.

1 34" side wall horizontal jig with 4 fixed clips

Altering The Back Wall Jig.

1. Measure 12" off the end of the 59" back wall jig and mark the location to cut.
2. Place it square on a miter saw using a nonferrous metal blade.
3. You must cut slowly to get a clean cut.
4. Use the provided joining plate to restore the back wall jig to its original size.
5. Place both pieces tight to each other, use a level or a straight edge to assure that the 2 pieces are in line.
6. Place the joining plate so that there are 4 screws on each side of the cut and tighten down.
7. Check with a level or straight edge to make sure that the 2 pieces are connected and stayed true.

The second Joining Bracket

This bracket is used to restore the vertical jig after altering it.

WARNING

Always wear eye protection when cutting any materials